

M24 magazine instructions

Warning: The magazine is designed ONLY for Altaros ATP brand ammunition and only for specific types of slugs. For **.22 caliber** it is **ATP King 5.50** (40gr). For **.25 caliber** is **ATP Queen 6.35** (60gr) + **ATP SMOOTH 6.35** (50gr) + **ATP KING 6.35** (66gr).

Never release the spring-loaded slide from the down position when the spring is compressed unless all rounds are in the magazine. Otherwise, there is a risk of it breaking off when the slide hits the upper stop.

1) Magazine loading procedure

Grasp the magazine with your left hand so that the shaft is facing up and the magazine opening is facing you. Grasp the triangular protrusion of the slide with your right thumb and insert the first slug with the rounded end forward (slanted with the flat facing out of the magazine) all the way to the magazine stop so that the slug can slide down the groove. Then slide the slide down with your thumb just enough to allow the next slug to be inserted (the previous slug serves as the bottom to hold the newly inserted slug). Do this until you have put all 5 slugs into the magazine. Then release the slider, which will hold the slugs in place thanks to the spring.

2) Inserting the magazine into the airgun

Note: The rifle's bolt must be in the closed position when loading the magazine, which is exactly the opposite of Remington 700 bolt action firearms. The magazine is inserted into the hole on the right side of the bolt body, which is located to the right of the ejection window.

Notice: in this hole there can already be a 2-round "hunting" magazine inserted from the factory, which must first be removed upwards and then a classic magazine can be inserted.

When loading, the magazine slide must be in a position facing away from the bolt body and the magazine plug must be facing up. In this position, all you have to do is slide the magazine all the way to the bottom so that the magnet on the magazine almost touches the magnet on the rifle.

3) Procedure for loading an airgun with a magazine

Airgun with a magazine is loaded in the same way as without a magazine, with the difference that it is necessary to open the bolt with a faster rearward movement, which ensures the correct guidance of the slug from the magazine into the feed groove of the bolt. When opening slowly, the slug may overturn, and this slug must then be removed, for example, by turning the rifle to the right, so that it falls out of the slot.

4) Exchange for a single-shot feeder suitable for other slugs or pellets

Open the bolt to the rear position and use your fingers to rotate the black cylinder of the magazine slug taker by 180 degrees. Then tilt the rifle almost 180 degrees to the right and the roller will fall out. Insert the single-shot silver magnet-slotted feeder so that it magnetically engages the bolt cylinder (the spring points toward the barrel). In a similar way, the one-shot feeder is exchanged for a magazine taker.